

ATTACHING, ADJUSTING AND ACHIEVING YOUR LIFT

Attaching, fitting and adjusting your Younger Hair® Face-Lifting wig is as easy as **1, 2, 3!**

1 ATTACHING your wig requires that you make sure that your face, in the areas around your temples and ears, is free of any oils, moisturizers, foundations or other cosmetics, as this will affect the Face-Lifting attachment's ability to stick to your skin. Pull the hair at the temples back and behind the ears. Cover the entire head with the Fish Net Cap.



2 ADJUSTING your Face-Lifting feature is as simple as tightening or loosening the clear plastic Face-Lifting device on the inside at the top of the head. Place your Younger Hair® Face-Lifting Wig on your head with the elastic bands at the back. Align the front of the wig with your own front hair line. Pull the back so it fits snugly at the nape of your neck.

You may need to adjust the hooks attached to the elastic at the nape of the neck to tighten or loosen.

3 ACHIEVING YOUR LIFT is simply a matter of cutting the double-sided tape strip in half and removing the paper from one side of the tape. Remove the paper from the other side of the tape and place on your face in front of your temples as shown. This tape will stick only to the face and not the hair at the temples. Once this tape has been positioned on the face, press the smooth tape-patch on the inside of the wig at the temple area, onto the tape to make a tight seal. Now go to the other temple and repeat. If you do not achieve a Face- Lift effect, remove the Face-Lifting Wig and tighten the Face-Lifting device a little at a time. It may take a few tries.

